

68—490 Install interior padding at bulkhead (after renewal of bulkhead)

Tools — commercially available

Hot-air fan approximately 600° C

e.g. "Jumbotherm" type K 25
Messrs. Zinser, 7333 Ebersbach/Fils

Install

- 1 Install padding and press on, slightly heat up with hot-air fan if required.
- 2 Center-punch at touching positions (three for the padding on the left and four for the padding on the right) and drill holes four millimeter diameter.
- 3 Attach padding with lock and cup-type pop rivet, part No. 910001 004106, at bulkhead.
- 4 Heat padding with hot-air fan or equivalent, firmly press on and allow to cool.

Attention!

Use gloves.